SONOTRAX SERIES

NO.	PART NO.	DESCRIPTION	List Price Exc VAT
1	01.60.410036-11	SONOTRAX Fornt Case	£5.00
	01.51.410042-10	Light Pipe	£2.00
2	01.55.461254-12	Protection Cover(Except Vascular&Lite)	£3.00
	01.55.14111-03	Label for Lite	£1.00
	01.55.14235-02	Label for Vascular	£1.00
3	01.51.14053-01	Power Button(Except Lite&Vascular)	£2.00
	01.51.14086-02	Power Button for Lite&Vascular	£2.00



NO.	PART NO.	DESCRIPTION	List Price Exc VAT
4	02.08.208045-11	LCD Module for Basic	£17.00
	01.55.14269	Sponge Mat For Basic LCD Screen	£1.00
	01.16.045089	LCD Module for BasicA&II&II Pro&Pro	£17.00
	01.55.14428	Sponge Mat 1	£1.00
	01.55.14429	Sponge Mat 2	£1.00
Turn to Next Page			



NO.	PART NO.	DESCRIPTION	List Price Exc VAT
5	02.03.451215-11	Mainboard for Basic	£93.00
	02.03.220055-11	Mainboard for Basic A	£118.00
	02.03.220054012	Mainboard for II	£203.00
	02.03.220052-11	Mainboard for II Pro	£203.00
	02.03.451260-11	Mainboard for Lite&Vascular	£51.00
	02.03.220053-11	Mainboard for Pro	£169.00
6	01.55.461505-12	Button Stickers for Basic&Basic A&II	£1.00
	01.55.461506-12	Button Stickers for Lite&Vascular	£2.00
	01.55.461507-12	Button Stickers for Pro&II Pro	£1.00
7	01.13.036168-10	Connector for II &II Pro (From Interface Board to Mainboard)	£2.00
8	02.02.451134-11	Battery Interface Board for II&II Pro	£7.00



NO.	PART NO.	DESCRIPTION	List Price Exc VAT
9	01.60.474052-11	Rear Case for II&II Pro (Rechargeable Model)	£5.00
	01.60.410037-11	Rear Case for Basic&Basic A&Pro&Lite&Vascular (Un-rechargeable Model)	£5.00
10	02.09.209002-10	Un-rechargeable Battery Module (Including Battery Cover) for Vascular&Lite&Basic&Basic A&Pro	£12.00
11	01.14.038020	Speaker	£3.00
	01.13.14042	Speaker Cable	£2.00
	01.55.36711	Sponge for Speaker	£2.00